

# E-Scooter user manual



**GoDrive**  
budějcký carsharing




## Scooter in the app

1. Book your scooter – driving range is displayed in the reservation window
2. Walk to the scooter and click Confirm reservation
3. Click the Start button in your app and check the scooter for any issues
4. Confirm the scooter is good to go – this will open the helmet box and start the engine
5. Take the helmet (L / XL), read the driver's manual and close the helmet box

## Scooter schematics

1. Front brake lever
2. Rear brake lever
3. Dashboard
4. Throttle
5. Right switches
6. Left switches
7. Rear light




read on




# Scooter controls




**GoDrive**  
budějcký carsharing



- 1. Speed display
- 2. Clock / error code display
- 3. Riding mode (inactive)
- 4. Mileage
- 5. Battery charge in %
- 6. Battery charge in bars
- 7. Data connection
- 8. Charging indicator



- 1. Lights
- 2. Horn
- 3. Indicator





- 4. Riding mode (inactive)
- 5. Hazard flasher
- 6. Parking button

- Scooter is on, just release the side stand up and slowly apply the throttle
- To turn off the scooter, press Stop in the app
- You can disengage throttle by pressing the parking button
- Only park where cars can park, including residential zones
- Do not park on the pavement, grass or reserved parking spots
- You can only end your reservation in one of the sharing zones in the app
- Before finishing your reservation, do not forget to return the helmet and close the helmet box
- Press End reservation

## ! Please drive responsibly:

- always wear a helmet
- mind the side stand up
- vehicles are not toys



# Have a safe trip!